

Art.	Descrizione	Description
01CI1000	<p>IMPATTOMETRO MOD. IMP/1200 Per urti leggeri con biglia da 50 g secondo la norma Annexe 7 Cahier CSTB 3778_V6 Juillet 2024 Base in acciaio inox 500 x 500 mm con riferimenti di centraggio completa di 4 piedi regolabili per il livellamento. Asta verticale in acciaio inox 1200 mm con supporto elettromagnete regolabile in altezza. Quadro elettrico da banco con interruttore, fusibili, spia presenza tensione e pulsante per il rilascio della biglia. Completo di biglia in acciaio 50 g</p>	<p>IMPACT TESTER IMP/1200 MOD. Suitable for light shock with ball of 50 g according to Annexe 7 Cahier CSTB 3778_V6 Juillet 2024 stainless steel base 500 x 500 mm with centering references complete with 4 adjustable feet for levelling. Stainless steel vertical rod 1200 mm with electromagnetic support and with adjustable height. Electric board with switch, fuses, light indicator of line presence and button for release the ball. Supplied complete with steel ball 50 g</p>
01CI0100/23	Biglia in acciaio 50 g	Steel ball 50 g



Art. 01CI1000